

Canon ImageRUNNER Advance DX: Remote Operation Software

This guide will go over downloading, installing & using the Canon Remote Operation Software Viewer that allows for remote operation of the copier/printer from a PC. Please note: This software is only available for PCs. (Not compatible with Macs.)

Download and Install:

- 1. Select the **hyperlink** below (or copy+paste into a web browser) to access the Canon Remote Operation Software webpage.
 - https://www.usa.canon.com/support/p/remote-operator-s-software-kit
- 2. Select the Software & Drivers button.
- 3. Select the computer operating system and version if not automatically detected.
- **4.** The software file compatible with the system will appear. Select the **Download** button. The download will begin.
- 5. Extract the *Remote_Operation_Viewer_Software_Vxxx.exe* zip file. Select location for extraction if prompted.
- 6. Locate and open the Remote_Operator_Software_Vxxx folder. Select the Setup.exe file.



7. An installer wizard window will appear. **Follow the instructions** in the wizard to install the software.

Using Remote Operation:

- **1. Open** the Canon Remote Operation Viewer from your PC.
- 2. Enter the **IP address** (or domain name) of the device to operate.

Enter the IP a the device to	addross (IPv4/IPv6) or o operate.	lomein name of
Address:	NOX X0X, X0X X0	•
(OK	Cancel



- 3. The remote software will display the main panel screen.
- **4.** If the display screen is black, press the *reset* button to wake the machine.

Helping You Succeed 🛛 🖪 📑 📁



Troubleshooting

Unable to Connect to the Canon MFP:

- 1. Confirm the machine is turned ON.
- 2. Confirm the computer is connected to the same network/WIFI as the copier.
- 3. Confirm the IP Address matches the Canon MFP.
 - **To find the IP Address at the Machine:** Select the Meter Count button on the bottomright corner of the screen. The IP Address will be listed on top of the new page.

If above is all correct, Check Machine Settings:

- 4. Confirm the Remote Operation Setting is set to ON in the Settings and Registration window.
 - Select ^ℜ Settings/Registration → Management Settings → License/Other → Remote Operation Settings → ON → Close.



