


Canon ImageRUNNER Advance DX: Printing Envelopes in

Microsoft Word from a MAC

Printing envelopes from the Mailings feature in Microsoft Word is a two-step process. First, setting up the multipurpose tray or paper drawers with envelopes. Second, printing from the Mailings feature in Microsoft Word.

Best Practices:

Flatten any curls, smooth envelopes out to remove any air, and align the envelopes on a flat surface. Do not use envelopes that have glue attached to their flaps, as the glue may melt due to the heat and pressure of the fixing unit. Envelopes may become creased, depending on the type and the condition in which they are stored.



©2023 Loffler Companies

MN: St. Louis Park; Duluth; Mankato; Rochester; St Cloud; Willmar, Grand Rapids; Thief River Falls | WI: Eau Claire; La Crosse; Green Bay IA: Sioux City; Spencer | NE: Norfolk | ND: Fargo; Grand Forks | SD. Aberdeen; Sioux Falls





Preparing the Paper Drawers Part 1:

Affix the appropriate envelope tools in the drawer. Drawer 1 uses both Envelope Tools A and B, while Drawer 2 only uses Envelope Tool A.


~~ /	While Drawer 2 only uses Envelope Tool A.		
In	In Drawer 1:		
1.	Fit Envelope Tool B around the paper guides. Face the side of the tool that does not indent towards the left of the drawer.		
2.	Remove the Envelope Feeder Attachment A stored in paper drawer 2.		
3.	Attach the Envelope Feeder Attachment A by aligning the protruding areas with the holes located on the bottom of the paper drawer.		
4.	The two Envelope tools work together to align the envelopes.		
5.	Close the flaps and load the envelopes so flaps are on the right side. Face up (flap down). <i>This example is for COM10 envelopes.</i>		

©2023 Loffler Companies

MN: St. Louis Park; Duluth; Mankato; Rochester; St Cloud; Willmar, Grand Rapids; Thief River Falls | WI: Eau Claire; La Crosse; Green Bay IA: Sioux City; Spencer | NE: Norfolk | ND: Fargo; Grand Forks | SD. Aberdeen; Sioux Falls







©2023 Loffler Companies

MN: St. Louis Park; Duluth; Mankato; Rochester; St Cloud; Willmar, Grand Rapids; Thief River Falls | WI: Eau Claire; La Crosse; Green Bay IA: Sioux City; Spencer | NE: Norfolk | ND: Fargo; Grand Forks | SD: Aberdeen; Sioux Falls





At the Computer:

Printing an envelope with the Microsoft Word feature.

	9 • • • • • • • • • • • • • • • • • • •	
1.	Open the Mailings feature in Microsoft Word.	O O P C C Decument1 Home Insert Draw Design Layout References Mailings Review View Acrol
2.	Select Envelopes from the toolbar.	Envelope Env
3.	In the Envelope tab, enter the delivery address and/or return address.	Anton, USA Font Position
4.	Select the Custom button.	Feturn Address If compared If compared <tr< th=""></tr<>
5.	Select correct Envelope Size.	Custom Page Options
	Note: Feed Method can be changed here if needed.	Envelope size: Size 10 (4 1/8 x 9 1/2 in) G Feed Method
6.	Select OK .	 Feed envelope face up Feed envelope face down Clockwise rotation Reset Cancel
7.	Select Print to be brought to the print driver.	Insert this envelope into the active document
		Mail Merge Print Cancel OK
8.	Go to Printer Options \rightarrow Paper Source.	Pape Auto
9.	Select the correct paper source from the dropdown menu.	Pape Drawer 1 Drawer 2 Drawer 3
10	Leave Paper Type to Auto.	Insert Sheets Settings
11.	Select OK .	Front/Back Cover Settings Carbon Copy Settings
		? Cancel OK
12	When all other desired settings are applied in the print driver, select Print .	Microsoft Word PDF Cancel Print

©2023 Loffler Companies

MN: St. Louis Park; Duluth; Mankato; Rochester; St Cloud; Willmar, Grand Rapids; Thief River Falls | WI: Eau Claire; La Crosse; Green Bay IA: Sioux City; Spencer | NE: Norfolk | ND: Fargo; Grand Forks | SD. Aberdeen; Sioux Falls



Troubleshooting (Print Driver):	
<i>Tip 1:</i> Leaving paper type as Auto is typically OK, but if there is an error message it may be due to paper type selected. Go to Printer Options → Paper Source → Paper Type and change to Envelope as shown to the right.	Paper Source: Multi-purpose Tray Image: Constant of the settings Paper Type: Envelope (75 to 105 g/m2) Settings Insert Sheets Image: Constant of the settings Image: Constant of the settings Front/Back Cover Settings Carbon Copy Settings
<i>Tip 2:</i> Make sure 1 sided is selected. Go to Printer Options → Finishing → Print Style: 1-sided Printing . Envelopes won't print if 2 sided is selected.	Print Style: 1-sided Printing Binding Location: Long Edge (Top) Gutter Misc. Finishing Modes Finishing Details Cancel

