








Xerox Altalink: Setting Defaults for Copy Settings at the Copier

<p>1. At the copier, select the Log In button on the front panel.</p>	
<p>2. Enter the Username. Note: The default Username is Admin.</p> <p>3. Select Next.</p>	
<p>4. Enter the Password.</p> <p>5. Select Done.</p>	
<p>6. Select the Copy icon.</p>	
<p>7. Select the desired settings that will become the new default.</p>	
<p>8. Scroll to the bottom of the screen and select Customize.</p>	
<p>9. Select Save Settings as Default.</p>	
<p>10. Select Save to confirm saving these settings as defaults. Note the confirmation message at the top left of the front panel.</p>	