
1 The Home screen



The Home screen appears after the PostBase Mini was turned on and the start routine has been successfully completed. Depending on the settings, you may have to select a user and enter the PIN.

I USA I