

Overview of symbols

Menu functions



Postage download



Display register report



Set franking date *(not in all countries)*



Print system



Print system information (display filling level)



Clean print system



Align cartridges



Replace cartridges



Calibrate cartridges



Change account



Remote Services / synchronize with data server



Account administration
(show list, set accounts to zero, switch account function on / off)



Special functions



Print advert only

Works Cited:

FP. "Operating Manual." PostBase Pro (DS) Support, Feb. 2014, download.fp-usa.com/product_docs/PostBase/PostBase-Econ/Documents-Manuals/postbase_manual_w_us_addendum.pdf.



Feed only



Seal only



Print numbers only



Imprint offset *(not in all countries)*



Auto postage download / set threshold



Display / clear down piece counter



Adjust display brightness



Brighter



Default



Darker



Display system info



Change ZIP code / place of posting *(not in all countries)*



Change language



Display / edit connection configuration (network / modem)








Withdraw machine *(not in all countries)*



Set tone signals

Works Cited:

-  Edit standby time
-  Edit 'Auto Off' time
-  Configure access control / PIN
-  Display contact information / change data center phone number
-  Set meter type *(not in all countries)*

Works Cited:

FP. "Operating Manual." PostBase Pro (DS) Support, Feb. 2014, download.fp-usa.com/product_docs/PostBase/PostBase-Econ/Documents-Manuals/postbase_manual_w_us_addendum.pdf.

Standard buttons



Open product calculation menu



Open Menu



Start franking / automatic feeder



Frank labels / print register on labels



OK / Finished / Confirm / Save



Cancel



Continue



Back



Edit / Change



'Differential weighing' mode on



'Differential weighing' mode off / normal weighing mode



Feeder: 'thick letters' mode on



Feeder: 'thick letters' mode off / normal mode



Start label printing / automatic feeding



Stop label printing / automatic feeding

Works Cited:

Error categories



General error



Printing plate error



Account error



Automatic feeder error



Print system error



Scale error



Label dispenser error



Jam



Security device error



Communication error with the PC



Postage calculation error



Communication error with FP infrastructure.

Works Cited:

FP. "Operating Manual." PostBase Pro (DS) Support, Feb. 2014, download.fp-usa.com/product_docs/PostBase/PostBase-Econ/Documents-Manuals/postbase_manual_w_us_addendum.pdf.