


47-116-25 MAGNETIC MEDIA SUPPORT ASSEMBLY

Magnetic Media Support Assembly fits over the Center Plate Support Bar. A strong magnet holds it tight against the Center Plate. Allows feeding of envelopes bottom edge first (*ie, flap is on the on trailing edge*) to prevent the flap from opening, catching or skewing the envelope. Helps prevent misprints and media jams. Use 1, 2 or more as needed for your print job.

47-116-25 Magnetic Media Support Assembly consists of (1) Assembly.
NOTE: It is strongly recommended that the Assembly be used in pairs.

Tools Needed: None



TO INSTALL:

1. Place the Assembly between Side Media Guides and over the Center Plate Support Bar as shown at right.

