AccurioPress C3080/C3080P/C83hc/C3070/C3070P/C73hc AccurioPrint C3070L

HOME > Adjustments > Finisher Adjustment> Staple Finisher(Fold) Adj. (Finisher FS-532)> Tri-Fold Position Adjustment

[Tri-Fold Position Adjustment]

Adjust the positions of [Fold 1]and [Fold 2]for Tri-Fold in **Saddle Stitcher SD-510** mounted in **Finisher FS-532**. Make this adjustment if the [Multi Half-Fold]position is not within the allowance range.

Objects of Adjustment: $[8.5 \times 11 \text{ w}]$, $[A4 \square]$, $[16K \square]$

NOTICE When adjusting both [Fold 1]and [Fold 2], be sure to start with the [Fold 1]adjustment. The position of [Fold 1]is calculated from the edge of the paper, while that of [Fold 2]is calculated from the position of [Fold 1]. Consequently, the measurement (b) in step 7 is subject to the change in either position of [Fold 1]and [Fold 2].

Press [Adjustment]on the [MACHINE]screen to display the [Adjustment Menu] screen.

2 Press [Finisher Adjustment], [Staple Finisher Adjustment], [Staple Finisher(Fold) Adj.], [Tri-Fold Adjustment], and [Tri-Fold Position Adjustment]in sequence.



i Tri-Fold Adjustment < Tri-Fold Position Adjust						
A Tri-Fold Position Adjuted and the second secon	stment >					
		I				
Touch [Set] to reflect the r	umerical value to curr	ent data				
Fold 1 Fold 2	Current Data	Adjust multi tri-fold posi Fold 1:[-]Extend [+]Shorte Fold 2:[-]Shorten [+]Exten Adjust fold 1 first when b	tion h d			
8.5x11D	+0	Adjust fold 1 first when b should be adjusted	oth fold 1 a	and fold	2	
MO	+ <i>G</i>	Adj. Range:-S0~+50 lstep = 0.1mm				
16KD	+8	-8				
				1	2	3
					_	
				4	5	6
				7	8	9
			+/_	0		Clear
		Set	/-			01601
		Print Mode				leturn

4 Press [Print Mode].

5 Load the paper size selected in step 3, then select that tray key.

✓ For [Output Setting], [Multi Tri-Fold]is automatically selected.

6 Press Start on the control panel.

A sample pattern will be output.

Measure the lengths (a) and (b) of the printed paper.

Paper Size	Allowance			
	а	b		
A4 🖬	95.0 mm ± 2.0 mm	101.0 mm ± 2.0 mm		
8.5 × 11 🖬	89.4 mm ± 2.0 mm	95.0 mm ± 2.0 mm		
16K 🖬	88.0 mm ± 2.0 mm	91.0 mm ± 2.0 mm		





Fold 2: [-] Shorten [+] Extend

V Use [+/-]to specify the value to be positive or negative.

The measurement (b) in step 7 increases with positive value entered, and decreases with negative value entered.

14 Press [Set]to enter the Current Data as the setting value.

15 Repeat steps 4 to 14 until the desired result is obtained.

16 Press [Return].

The screen returns to the [Tri-Fold Adjustment Menu]screen.

Press [Close].

/