


Scan to and Print From Memory Media





Note:


Standard support for printing TIFF/JPEG files, Optional support for printing PDF files (Requires PS Printer Kit or Direct Print* (for PDF/XPS) Kit)




I. Set-up Display for Memory Media Function


- 1. The default setting for displaying memory media is 'Off'.
- 2. To set to "On', Press [Settings/Registration] on control panel.
- 3. Select [Preferences].

Select [Display Settings].



4. Select [Store Location Display Settings]







- 7. Select [Preferences].
- 8. Select [External Interface].
- 9. Select [USBSettings]
- 10. Select [On} for Use USB Device
- 11. Power Off and On the device


Select an item to set.		
Top Preferences	Paper Settings	
reletences	Display Settings	
	Timer/Energy Settings	_
	Vetwork	1/2
L Up	External Interface	
		Close J




II. Scan and Store to USB Memory Media

1. Select the [Scan and Store Function from the Main Menu].










5. Select a folder or location to store scanned documents. You can also create a new folder by selecting the [Create Folder] button.

01					
🗸 Тура	a Name		▲ Size	Date/Time	
D	New Task Force			09/04 5:37PM	
	SE 2009			09/04 5:37PM	
D	Susie			09/04 5:37PM	3/4
D	VI Images			09/04 1:39PM	
0	0206 kickoff			02/06 7:30AM	
D	2009-07-07			07/07 12:26AM	
			Total:21	Selected:0	
		Details	Create Folder	▶ Delete	

- 6. Place your originals in the Document Feeder or on the Platen glass.
- 7. Press [Scan]

	flet/			canned data.				
🖌 Тур	e Nami					Size	Date/Time	
4	Camp	aign leaf]	let. pdf			384. 1KB	09/04 5:44PM	1
	Orde	r form.pdf				701.5KB	09/04 5:44PM	
1	Summ	er Special	l. pdf			1.06MB	09/04 5:43PM	1/
t Up		₹ ¥ Upda	te	Folder Operations	Tota	il:3 I: 93%	Selected:0	
	ear lection		Details		Edit Fil	e ,		







 Use keyboard on touch screen or optional external keyboard to name the document.
 Press [OK]

Note:

- Device will assign the file extention
- You cannot use the following characters in a file name: \/:, *? " <> |
- You cannot use . (period) or space for the first or last character of the file name
- If you create a file without assigning it a name, the machine automatically assigns the file a name using the year, month, day and time the file was created.





 Select [•
 Click [Remove] button. Select [OK]. Remove USB Memory Media 	Select the memory media List Memory Media (A:) 1/1 Remove
	OK 🤳 Remaining 🖬 LTR paper is low.



III. Access Stored Files and Print from USB Memory Media

1. Select the **[Access Stored Files]** Function from Main Menu

Note:

 Location of button may be displayed differently than what appears in this screen shot due to customization settings.



- 2. Insert [USB Memory Media]
- 3. Select [USB Memory Media]

Note:

- Standard USB Port located onright saide of control panel
- Optional support also offered for Memory sticks, SD cards, Compact Flash, Microdrive



4. Select [Memory Media (A:)] to view your	Access Stored Files 👷 Copy	Fax/I-Fax
files.	Select the location to use the file.	
	🥩 Memory Media	
	Type Name	Available Capacity
	🤣 Memory Media (A:)	765.2MB 963.7MB
		1/1
		- A. - V
		w.
	Lup Check Media	
	D System Management Mode	Log Out



Fax/I-Fax

Date/Time

08/21 3:32PM

08/21 3:33PM

Selected:0

Carl Log

1

1/1

🔊 Copy

Folder Operations

A Size

Used: 20% Edit File

- Open a folder to locate the file you want to 5. print.

6. Select the file

Note:

- When there are two or more files stored in the memory media, you can press [Name] or [Date/Time] to sort the list of files
- If PS Printer Kit or Direct Print Kit is not • installed, PDF files cannot be printed. You can view them, but the Print button will be grayed out.
- XPS file formats cannot be printed
- You can select and print up to six files in same memory media. However, you cannot select and print files with different file formats or a folder and a file at the same time.
- You can only select multiple files when files are stored n the same folder.

Sel	lect a	file and speci	fy the pu	rpose.					
21	/Proj	ect 2/							
-	Туре	Nama			Si	ze			
	-	Environment	al Advoca	acy. pdf	2.5	93MB	08/21 3:47	7PM	
									100
									1/1
									1/1
			1			_			-
t	Up	44 Ut	odate	Folder Operations	Total:1 Used: 2	20%	Selected:0	7	
t				Operations	 Used: 2	20%	Selected:0		
t	Clea		odate Details	Operations		20%	Selected:0	7	

Access Stored Files

🖌 Type Name

Clear Selection


D System Management Mode

t

📁 Project 1

Project 2

++





- 8. Adjust print settings if desired. To print all pages press [All Pages]. To specify which pages to print, press [Specify Pages].
- 9. Select [Start Printing].

Note:

- You can set paper selection, 2-sided printing, finishing and Special Features.
- Device will start processing your print job
 Screen automatically closes at the end of the job



- 10. Select [) button on bottom of screen to safely remove USB Memory Media
- 11. Click [Remove] button.

