

11. Loosen a stack of envelopes and place the stack on top of the bottom envelope between the side guides.



If envelopes are warped the envelope support can be set at an angle to better guide the flow of envelopes.

Fill the Sealing Liquid Reservoir



1. Open the front cover **B**.
2. Fill the reservoir **A** to the "Max" lip with sealing liquid.
3. Close the front cover **B**.

Before starting the job, wait approximately 5 minutes for the brushes to moisten or use moistened brushes. For instructions on the installation of brushes, see the User Guide, section [Clean and replace brushes](#) on page 125.
