

POLYCOM PHONE USER GUIDE – VVX450

Placing a Call

- Lift handset
- Dial extension press a speed dial, or dial a 10-digit phone number

Answering a Call

- Lift handset **OR** Press headset or speaker button

Placing a Call on Hold

- While on a call press **Hold**
- Line key will flash

Retrieving a Held Call

- Press Resume or the flashing line key

History/Redial

- Press the Left side of Circle to scroll through your Received Calls
- Press the Right side of Circle to scroll through your Placed Calls
- Press the Bottom of Circle to scroll through your Missed Calls
- Press Dial to call

Park

- With a call connected, Press **More**
- Press **Park** - it will read out the extension it is parked at

Retrieving a Parked Call

- Dial the extension the call is parked at

Do Not Disturb

- press **DND**

Disable Do Not Disturb

- press **DND** again

Transferring a Call

Blind Transfer

- While on a call, press **Transfer**
- Dial number
- Hang up or Press **Transfer** again

Consult Transfer

- While on a call, press **Transfer**
- Dial number
- Wait for the Party to answer, Announce the call
- Hang up to complete the transfer

Transfer to Voicemail

- While on a call, press **Transfer**
- Dial *+ extension you want to transfer to
- Hang up

Conference Calls

- While on a call, press **More**
- Press **Confrnc**
- Dial number to add
- Press **More**
- Press **Confrnc** again and all parties will be connected

Note: Press More, Split to Split apart the conference, to join the calls back together, press resume so you are talking with one of the parties, press More, Join

Forwarding

- Press **Forward**
- Select when you want to Forward: Always, No Answer, Busy
- Enter in the number you want to forward to
- Press **Enable**

Disable Forwarding

- Press **Forward**
- Select the Forwarding option you want to disable
- Press **Disable**

Hard Keys

Transfer – sends a call to third party

Messages – Calls Voicemail

Hold – Places a call on Hold

Back – Brings you back one menu level

Home – changes options and settings

Headset – Press this to use a headset

Mute – Makes it so people can't hear you

Speaker – Takes phone off hook

Left side of Circle – Received Calls

Right side of Circle – Placed Calls

Bottom of Circle – Missed Calls

Top of Circle – Favorites

Center of Circle – Select

Soft Keys

New Call - Generates dial tone for a call
Directory - Save/Access your Contacts
Forward - sends call to another number
DND - Sends calls directly to voicemail
Dial - dials the number
Hold - Places a call on Hold
Resume - takes a call off hold status
Transfer - Transfers a call
Blind - Transfers a call Blind
Consultative - Transfers a call and lets you talk to the third party.
More - Lists more options
Directory, Corporate Directory, recent calls, or favorites
Conference - Initiates/completes a conference
Split - Splits a conference call apart
Join - Merges two calls into one call
Manage - Manage the conference call
Far Mute - Mutes highlighted party
Remove - Removes highlighted party
Info - Information on the Participant
Back - Brings you back one screen
Lines - Shows the lines that are in use
Calls - Shows the calls that you are on
Park - Parks a call on the system that anyone can pick up by dialing the park extension listed when the call is placed on park
Call Flip - Flips the call to the Desktop or Cell phone app
End Call - Hangs up an active call
Cancel - backs out of transfer or conference screen
Reject - Transfers call to your voicemail or forwarding condition
Select - chooses highlighted option

Audio Control

Located in the bottom center of the phone, increase volume by pressing + and decrease volume by pressing -

- Change the ringer volume while in idle mode or while phone is ringing
- Pick up the handset or press the speaker button to adjust volume settings for each

Changing Ringtone

- Press Home
- Scroll to Settings (7)
- Choose 1 for Basic
- Choose 4 for Ring Type
- Select your Ringtone
- Press Home to Exit

Enabling a Headset

There are two ways you can make a headset work;

- Plug in the headset to the headset plug on the back of the phone
- Press the Green Headset Button
- Press the Button on the side of the headset to get dial tone

Note: The Headset Button will have to be pressed every time you answer or place a call, not a True Wireless Solution

The other option is:

- Plug EHS (Electronic Hook Switch) in to the headset plug on the back of the phone
- Press Home on your phone
- Choose Settings (7)
- Choose Basic (1)
- Choose Preferences (1)
- Choose Headset (3)
- Choose Headset Memory (1)
- Choose Enabled (2)
- Press Back
- Choose Hookswitch Mode (2)
- Choose you Headset Type
- Choose Yes
- Your Phone will reboot
- Press the Button on the side of the headset to get dial tone

LOFFLER